

HT-630 Communication Issues

I can't find the correct Com port for the HT-630 when I open the 'PT-Comm Manager'!

Open your Device Manager and click onto the 'Ports (Com & LPT) folder.

Look for a port labeled 'USB Serial Port (Com?)'

The number in the () is the port number that you need to use in the 'Open Portable Window' when running the 'PT-Comm Manager'.

If there is no port labeled USB Serial Port (Com?), you will need to install the USB driver from the CD that came with the HT-630. If you can't locate the CD you can download the driver from <http://us.ute.com/>. Click onto 'Products' - 'HT630' - 'Download' - 'Supporting Software' - 'USB Driver'.

